

#114 - HALYARD INSTALLATION INSTRUCTIONS.

#114 / Page 1 of 1

1. Place halyard grip, on the side of the mast, 36" to 48" below the forestay/shroud tang so that the slot in grip is in facing the back of the mast (luff track).
2. Mark the 2 attachment hole locations.
3. Center punch each mark.
4. Drill holes using 13/64" drill.
5. Place rivet sleeves into holes.
6. Place fitting, as described above, over sleeves.
7. Place rivets through fitting and into sleeves.
8. Pull rivet mandrels/ set rivets with rivet gun.

www.hobiecat.com



Dealer 1 (800) HOBIE-49

#114 - HALYARD INSTALLATION INSTRUCTIONS.

#114 / Page 1 of 1

1. Place halyard grip, on the side of the mast, 36" to 48" below the forestay/shroud tang so that the slot in grip is in facing the back of the mast (luff track).
2. Mark the 2 attachment hole locations.
3. Center punch each mark.
4. Drill holes using 13/64" drill.
5. Place rivet sleeves into holes.
6. Place fitting, as described above, over sleeves.
7. Place rivets through fitting and into sleeves.
8. Pull rivet mandrels/ set rivets with rivet gun.

www.hobiecat.com



Dealer 1 (800) HOBIE-49

#114 - HALYARD INSTALLATION INSTRUCTIONS.

#114 / Page 1 of 1

1. Place halyard grip, on the side of the mast, 36" to 48" below the forestay/shroud tang so that the slot in grip is in facing the back of the mast (luff track).
2. Mark the 2 attachment hole locations.
3. Center punch each mark.
4. Drill holes using 13/64" drill.
5. Place rivet sleeves into holes.
6. Place fitting, as described above, over sleeves.
7. Place rivets through fitting and into sleeves.
8. Pull rivet mandrels/ set rivets with rivet gun.

www.hobiecat.com



Dealer 1 (800) HOBIE-49