

# #14709\_14710 - H16/H17 TRAPEZE RETURN SYSTEM.

**Hobie 16** 1. Install 2 mini-blocks in underside of each side bar using eyestraps and self tapping screws provided in kit. Use a 1/8" drill bit. Locate each block at approximately the same place the trapeze shockcord exits from under the trampoline.

2. Install shockcord snap hook on one end of each trapeze shockcord.

3. Route each trapeze shockcord per the diagram.

4. Install other shockcord snap hook after routing each shockcord.

**Hobie 17** 1. Install mini-blocks with eyestraps on deck lip, under trampoline, about 9" to 12" behind front crossbar. Use 8-32 x 3/4" screws and nylock insert lock nuts provided.

2. Install plastic shockcord snap hook on one end of shockcord. Thread other end of shockcord through trapeze shockcord grommet, from top and thread through pulleys per diagram.

3. Install plastic shockcord hook on end of shockcord. Note: The trapeze wires will not be drawn tight by shockcord except when wings are installed. If sailing without wings, take up excess shockcord between the pulleys with an overhand knot.

