

# #1491 & 1492 - ANTI - CHAFE TAPE.

1. Remove battens from pockets to be covered.
2. Located the center of batten pocket chafe point by using the following table. (Measuring back from the luff).

BOTTOM BATTEN	Hobie 14	Hobie 16
#1	29"	37"
#2	17"	29"
#3	6"	23"
#4	--	16"
#5	--	11"

3. Clean soil and water marks with alcohol or mild detergent. Allow ample time to dry. Peel off the paper backing from the tape and apply the tape to the batten pocket so that the tape overlaps 6" each side of the center of the chafe point.
4. Place the sail on a flat, smooth surface; cover with cotton cloth and heat tape through cotton cloth with a warm iron. Once applied DO NOT LIFT THE TAPE TO REPOSITION. If you have to replace the tape for some reason, new a fresh new piece.
5. Sail is now ready to use.



# #1491 & 1492 - ANTI - CHAFE TAPE.

1. Remove battens from pockets to be covered.
2. Located the center of batten pocket chafe point by using the following table. (Measuring back from the luff).

BOTTOM BATTEN	Hobie 14	Hobie 16
#1	29"	37"
#2	17"	29"
#3	6"	23"
#4	--	16"
#5	--	11"

3. Clean soil and water marks with alcohol or mild detergent. Allow ample time to dry. Peel off the paper backing from the tape and apply the tape to the batten pocket so that the tape overlaps 6" each side of the center of the chafe point.
4. Place the sail on a flat, smooth surface; cover with cotton cloth and heat tape through cotton cloth with a warm iron. Once applied DO NOT LIFT THE TAPE TO REPOSITION. If you have to replace the tape for some reason, new a fresh new piece.
5. Sail is now ready to use.

