

#16713 - NON-SKID TAPE.

#16713

Instructions

1. Apply at temperatures between 60-80 degrees F to a cool, clean surface.
2. Cut tape to length suitable for area requiring non-skid surface. Cut sharp corners by rounding to an approximate ¼" radius with scissors or sharp blade.
3. Remove backing paper at one end and apply to area to be covered.
4. Slowly remove backing paper at a sharp angle as you apply the tape.
5. When in correct position, smooth down firmly.
6. Allow 24 hours before abusive use.

www.hobiecat.com



Dealer 1 (800) HOBIE-49

#16713 - NON-SKID TAPE.

#16713

Instructions

1. Apply at temperatures between 60-80 degrees F to a cool, clean surface.
2. Cut tape to length suitable for area requiring non-skid surface. Cut sharp corners by rounding to an approximate ¼" radius with scissors or sharp blade.
3. Remove backing paper at one end and apply to area to be covered.
4. Slowly remove backing paper at a sharp angle as you apply the tape.
5. When in correct position, smooth down firmly.
6. Allow 24 hours before abusive use.

www.hobiecat.com



Dealer 1 (800) HOBIE-49

#16713 - NON-SKID TAPE.

#16713

Instructions

1. Apply at temperatures between 60-80 degrees F to a cool, clean surface.
2. Cut tape to length suitable for area requiring non-skid surface. Cut sharp corners by rounding to an approximate ¼" radius with scissors or sharp blade.
3. Remove backing paper at one end and apply to area to be covered.
4. Slowly remove backing paper at a sharp angle as you apply the tape.
5. When in correct position, smooth down firmly.
6. Allow 24 hours before abusive use.

www.hobiecat.com



Dealer 1 (800) HOBIE-49