

# #1791 - CUSTOM TIE DOWN.

#1791 / Page 1 of 1

## Parts List:

4 - Tie down straps

## Installation on the trailer:

Attach a tie-down strap at each vertical roller guide. To do so, remove the U bolt nut that retains the vertical roller guide and place the tie-down strap plate on the U bolt then replace the nut. Use the nut on the front of the trailer cross beam for the front straps and the rear of the trailer cross beams for the rear straps.

Insert the hook end of each strap into the eye strap (for trampoline wire) at each end of the front cross bar, front and rear

Pull the slack out of the strap and tighten it by use of the metal over center cam in the middle of each strap. Don't take so much slack out of the strap that it tends to bend the trampoline eye strap when the over center clamp is actuated.

That's it!

[www.hobiecat.com](http://www.hobiecat.com)



Dealer 1 (800) HOBIE-49

# #1791 - CUSTOM TIE DOWN.

#1791 / Page 1 of 1

## Parts List:

4 - Tie down straps

## Installation on the trailer:

Attach a tie-down strap at each vertical roller guide. To do so, remove the U bolt nut that retains the vertical roller guide and place the tie-down strap plate on the U bolt then replace the nut. Use the nut on the front of the trailer cross beam for the front straps and the rear of the trailer cross beams for the rear straps.

Insert the hook end of each strap into the eye strap (for trampoline wire) at each end of the front cross bar, front and rear

Pull the slack out of the strap and tighten it by use of the metal over center cam in the middle of each strap. Don't take so much slack out of the strap that it tends to bend the trampoline eye strap when the over center clamp is actuated.

That's it!

[www.hobiecat.com](http://www.hobiecat.com)



Dealer 1 (800) HOBIE-49