

***INSTALLATION INSTRUCTIONS
WAVE MAST FLOAT FOR HOBIE 14 OR HOBIE 16***

There are 4 possible installations for the Wave Mast Float to the Hobie 14 or 16. Be sure to follow the applicable instructions. Every Wave Mast Float comes with the mounting bracket already installed to the float. All that remains to be done is to attach the mast float by following the proper installation to mast head instruction.

- 1. Hobie 14 with Comp Tip Mast Head.** This mast uses the same mast head as the Hobie Wave. All that needs to be done is to remove the two clevis pins holding the two sheaves in place and replace them with the 2 each 10-32x1 1/2" machine screws. Remove one clevis pin, slide the Mast Float and Bracket over the mast head, align a set of screw holes and install the screw. Take caution not to allow the sheave to slip out of the casting. Should it fall out it is possible that the sleeve/sheave bearing will be lost. Repeat for the second sheave.
- 2. & 3. Hobie 14 and Hobie 16 without Comp Tip Mast Head.** Tools required are a number 20 drill, a 10-32 tap and a drill motor. Place the Mast Float and Bracket over the mast head casting such that the centerline of the float is perpendicular to the center line of the mast. Make a mark on the casting at each of the 4 holes in the bracket. Remove the bracket and drill and tap the 4 holes. Caution: Avoid drilling into the sheave if possible. Using the 4 each 10-32 by 5/16" screws and lock washers secure the Mast Float to the mast head. The Hobie 16 mast head casting is narrower than the Hobie 14 and it will therefore require that the ears on the bracket be bent in.
- 4. Hobie 16 with Comp Tip Mast Head.** Tools required are a 3/16" drill and a drill motor. Remove the rivet that holds the rear sheave in place using the 3/16" drill. Install the Mast Float and Bracket to the mast head using one of the 10-32x1 1/2" screws and nuts in the rear sheave location. Mark a place on the bracket ear per the sketch on page 2 and drill a 3/16" hole all of the way through the bracket ears and mast head. Install the second 10-32x1 1/2 screw and nut with the two washers on either side of the mast head to take up gap.

#30116 - MAST FLOAT "BABY BOB" FOR HOBIE14 & HOBIE16

