

## #50012 - ROLLER FAIRLEAD KIT.

#50012

### Instructions

1. No need to remove cam cleat from boat.
2. Remove bulls eye fairlead.
3. Place screws through plate.
4. Place tubular spacers on screws.
5. Place sheaves on spacers.
6. Place assembly over screw holes for bulls eye and screw in.
7. If sheaves drag on pivot, place flat washers on bottom of spacer to raise assembly.

[www.hobiecat.com](http://www.hobiecat.com)



Dealer 1 (800) HOBIE-49

## #50012 - ROLLER FAIRLEAD KIT.

#50012

### Instructions

1. No need to remove cam cleat from boat.
2. Remove bulls eye fairlead.
3. Place screws through plate.
4. Place tubular spacers on screws.
5. Place sheaves on spacers.
6. Place assembly over screw holes for bulls eye and screw in.
7. If sheaves drag on pivot, place flat washers on bottom of spacer to raise assembly.

[www.hobiecat.com](http://www.hobiecat.com)



Dealer 1 (800) HOBIE-49

## #50012 - ROLLER FAIRLEAD KIT.

#50012

### Instructions

1. No need to remove cam cleat from boat.
2. Remove bulls eye fairlead.
3. Place screws through plate.
4. Place tubular spacers on screws.
5. Place sheaves on spacers.
6. Place assembly over screw holes for bulls eye and screw in.
7. If sheaves drag on pivot, place flat washers on bottom of spacer to raise assembly.

[www.hobiecat.com](http://www.hobiecat.com)



Dealer 1 (800) HOBIE-49