
What Comes With Your Kayak?


- 2. Seat
- 3. MirageDrive (2 parts)
- 4. Rudder 5. Paddle
- 6. Cassette Plug





Pedal Adjustment

Adjust cranks by rotating and clicking them into the desired position. Make sure both cranks are in the same position number.






Seat Adjustment

To adjust, pull down on loop of straps for less recline in the seat. For more recline, release the tension in the




On the Water




Steering

The steering handle is located in the middle on the left/port side of the




Paddle Assembly



Fishfinder Plate (Passport 12.0 only)

from Fishfinder plate on bottom


of hull. Follow instructions on your Fishfinder kit or installation.



Shallow Water and Beaching



Press either pedal forward in shallow water to raise fins. Pressing one pedal fully forward will orient the fins with the kayak underside to allow beaching.



Additional Storage Key Points

Always remove all water from boat

Storage and Transport

Storage Do's

Place your boat upside

down on crossbars or

hang from wide strapping

Storing your boat cockpit

side up on crossbars can

Storing your boat on its

side over a long period of time can flatten/dent the

Hanging the boat by the

scuppers can distort the

Never hang the boat by

handle long-term load

They are not designed to

Never use PVC runners or tubes to store boat on.

handles or pad eyes.

scupper holes.

and will fail.

are recommended ways

for proper storage.

Storage Don'ts

dent the bottom.

sides.

- Don't leave tie-down straps tight over a long period of time
- Storing in non-recommended configurations can result in hull damage and can void your warranty

Roof Topping


The best way to transport your boat is to purchase a trailer or roof rack from your dealer. Using proper cradles that support the hull, the boat can be transported right side up. Straps can then be laid across the boat and tied to the rack bars. Straps should be tight, but not so tight that they distort the shape of the boat. Avoid using ratchet straps to prevent overtightening.



Be sure to consult your car and roof rack owner's manual to ensure that you comply with all recommendations, precautions and specifications.


Running a line or strap from the bow and stern of the boat to each bumper is required. If your bumpers do not have a gap to pass a rope around, look underneath. There should be a loop of metal, which is used by car transports such as tow trucks.

Many people like to use the scupper holes to tie the boat to the car. This helps prevent the boat from sliding back and forth or the tie-down rope from slipping off the boat. (This is an acceptable method for tying the boat down for transport.)



Maintenance and Care

MirageDrive Regular Maintenance



Warranty

It is very important that you complete and send us your Warranty Registration Card as soon as possible.

This information enables Hobie Cat Company to contact you should there be important product information that needs to be shared with you in a timely manner. Please complete the Warranty Registration Card in your Owner's Packet, or take advantage of our online option at:

http://www.hobie.com/product-registration

Scan this QR code with your smart phone



If you have a question or issue with your Hobie product, please see your Authorized Hobie Kayak Dealer. They will assess the problem, assist with a repair and file a warranty claim with Hobie Cat Company, if needed. All warranty claims must go through your Authorized Hobie Kayak Dealer. The Warranty Registration Card and Warranty Policies are included with each model in the Owner's Packet. Type in the address below to go to our dealer

All specs, colors, graphics and features are subject to change without notice. Please refer to the website for complete details.

http://www.hobie.com/dealers

Safety

Checklist

Always:

Please read through the owner's information package prior to using this

The user of this product acknowledges both an understanding and assumption of risk involved in paddle/pedal sports. Consult your physician prior to

- Wear a Coast Guard approved personal flotation device (lifeiacket)
- Dress appropriately for weather conditions: cold water and/or weather can result in hypothermia; apply sunscreen and wear sun protective clothing
- Check your equipment prior to each use

If you fall out of your boat, stay with the boat. You should be properly wearing

a life jacket/PFD which will keep you afloat. If the boat is upside-down, it will

the scupper hole or the Hobie MirageDrive and pull the boat upright. Position

need to be turned over. To do this, reach across the bottom of the boat and grab

yourself so your head is near the cockpit area of the boat and you are facing the loat. You will want to be between the seat and the footwell areas of the boat. Reach across the boat to the far edge with one hand. Place the other hand on the near-side rail, then kick with your feet, pulling yourself up and onto the boat. Roll over onto your backside toward the seat, which should place your backside in the seat. Sit up, swing your feet into the footwells and you're ready

- for signs of wear or failure. • Secure a safety leash to your paddle and MirageDrive ..
- Scout unfamiliar waters. • Be aware of river water levels, tidal
- changes, wind conditions, obstacles in and above the water and weather changes. Always make sure that your hatches are secure and closed.
- Carry a pump and/or bailing device. Always carry the spare paddle provided with the hoat

Getting into your Boat

Hobie Cat Company

1-800-HOBIE-49

1-800-4-HOBIE

Toulon, France

Hobie Cat Europe

+33 (0) 494 08 78 78

Hobie Kayak Europe

+31 (0) 187 499 440

+55 (21) 3942 6815

Hobie Cat Brasil

Stellendam, The Netherlands

Porto Belo, Santa Catarina, Brazil

Hobie Cat Australasia

Oceanside, California, USA

Huskisson, New South Wales, Australia

Never:

- Drain plug locations to make sure they are properly installed • Never exceed your ability and be aware of Getting in and out of the boat from a capsized state your limitations.
- Never use alcohol or mind-altering drugs
- · Never open your hatches in unstable water conditions
- hull. They are installed for structure. additional flotation and safety

- Never go alone and always file a float plan.
- Never go in flood and/or fast moving water conditions. Hobie kayaks are not designed for fast moving water.
 - Taking the kayak sail down on the water (if applicable)
- prior to or while using this product.
- Never remove the foam pieces inside the

Mirage Kayak Cassette Plug

Rudder operation

Closing hatches properly

Shakedown Cruise

Your Hobie is shipped with a Mirage Cassette Plug. The plug is provided as standard equipment in the Mirage Kayak package. Insert the plug into the Mirage well when the MirageDrive is removed to provide added safety and to "fair" the bottom of the hull when paddling.

MirageDrive installation, adjustment and removal

As with any new product, it is important that you become familiar with the boat

and all its features. It is also important to determine that the boat is sound before long trips. We recommend that you do what we call a "shakedown cruise"

calm conditions where you can familiarize yourself with or test the boat before

taking any long trips into open water. Things you should check or practice are:

when the boat is new, after shipping or transport, before long trips and after installing any thru-hull fittings. This test is typically done in shallow,



hobie.com

PN 77800080 **REV 190307**





PASSPORT ASSEMBLY INSTRUCTION MAP


Follow these steps to complete the basic set up of your new Hobie Mirage Passport!

Make sure to watch this Quickstart Video before using your Hobie product.

www.hobie.com/quickstart/passport10.5

TOOLS NEEDED:

phillips head screw driver



9/16" wrench




Drive Assembly

(1a)

a. Squeeze the crank adjusters to move the locking pin out of the way.

b. Insert the cranks into the drum while still squeezing the adjusters.


c. Once both cranks are in place and aligned with the bolt holes, fasten them to each side of the drum with the hex head bolts and a 9/16" wrench.



Drive Installation


a. Lower drive straight down into well, making sure the spine is level. With a swift push downward, the drive will lock into the well automatically.

b. Double check the Click and Go levers are pushed toward the bow and in the locked position before pedaling.



Drive Release

c. To release the drive, pull each Click and Go lever towards the user and pull the drive straight








Rudder Installation

a. Fasten the rudder to the inserts in the recesses at the back end of the kayak. Insert the steering rod into the rudder pivot and secure by tightening the adjustment knob.

b. To adjust, center the steering handle and tighten the knob over the rod, by turning clockwise.



Seat Installation a. Place the seat in the kayak so the bottom of the seat frame rests in the channel at the rear of the cockpit and atop the raised seat platforms at the front. Lock the seat into place by turning the knob lock over the

b. Extend the seat straps forward and clip them to the pad eyes fixed to the hull.

