




1. Depending on which wheel style is used with the dolly, slide the telescoping inner axle to the appropriate location on the outer axle.





2. Secure the inner axle and webbing strap to the outer axle using the 1/4" bolt and nut.



3. Slide the wheels on the inner axles and secure with keeper pin.



4. Slide the carry handle into the tube on the dolly frame and secure with keeper pin.



5. Slide dolly under hull to a nearly balanced position. Secure dolly to hull using webbing strap and buckles. *Note: Fit to hull is universal and not a perfect match on any model.*



6. The carry handle can remain on the dolly during use under the kayak. The webbing straps can be secured to avoid dragging while transporting the dolly.

